


VITZTHUM column former

VITZTHUM-Baurohr

Schalbau
VITZTHUM



Zentrale
Schalbau Vitzthum Niederland 214
5091 Unken, AUSTRIA
www.vitzthum.com
info@vitzthum.com

This Installation Guideline is a condensed description of factors having a direct effect on the performance of the Product and is based on the present state of the art. It may be necessary to alter these recommendations, as more information becomes available. Correct use is the responsibility of the user, if in doubt please consult your local supplier.

Diese Einbauhinweise können nur als Empfehlung gelten. Sie ersetzen nicht das für die Montage erforderliche Fachwissen. Die Hinweise werden stets auf dem neuesten Stand der Technik gehalten und werden ständig aktualisiert. Technische Änderungen sind daher – auch ohne vorherige Information des Kunden – ausdrücklich vorbehalten. Die jeweils gültige Version ist auf unserer Website unter: www.maxfrank.com zu finden. Ergänzend gelten unsere Allgemeinen Verkaufsbedingungen.